

AAM 38F USER MANUAL



Copyright © Eltra SPA Unipersonale. All rights reserved.

The contents of this documentation are protected by copyright by Eltra SPA Unipersonale.

This documentation may not be altered, expanded, reproduced nor circulated to third parties, without the prior written agreement of Eltra.

The brands and product names mentioned in this publication are trademarks or registered trademarks of their respective title holders.

Liability to modification without notice

Eltra reserves the right to make changes without further notice to any products or data herein to improve reliability, function, or design.

Warranty disclaimer

Information furnished by Eltra is believed to be accurate and reliable.

However, Eltra does not assume any liability arising out of the application or use of this information, nor the application or use of any product or circuit described herein, neither does it convey any license under its patent rights nor the rights of others.

The specified product features and technical data shall in no case not constitute a guarantee declaration.

Document information

Revised

06/2024 - Template updated

12/2018 - Template updated

06/2016 - First release

Eltra SPA Unipersonale

Via Guido Salvagnini, 17

36040 Sarego (VI)

Italy

Phone: +39 0444 436489

Fax: +39 0444 835335

www.eltra.it

eltra.it@broadcom.com




TABLE OF CONTENTS

TIMINGS	Timing diagram	4
AAM 38F BISS	Register Communication and Assigment	4
	Memory Map	4
	Slave Register Description	5
	Alarm Definition	5
	General installation notes	6

BISS-C TIMING DIAGRAM

Parameter	Symbol	Value			Unit	Note
		Min	Typical	Max		
MA frequency	f_{MA}	0,08	–	10	MHz	1
Busy	T_{busy}	$2 / f_{MA} + 3,35 \mu s$	–	$2,5 / f_{MA} + 3,75 \mu s$	μs	2
Timeout	$t_{Biss-timeout}$	$1,5 / f_{MA}$	–	$1,5 / f_{MA} + 90 ns$	ns	2

Figure 1 Timing Characteristics of MA and SLO



1. MA low-time = $0,50 / f_{MA}$; high-time = $0,50 / f_{MA}$
2. Refer to Figure 1 for timing description
3. CRC Polynomial = Invert of $(X6 + X1 + X0)$
4. nErr bit is active low. (Combine all the Error Status and reflect in nERR bit)
5. nWar bit is active low. (Combine all the Warning Status and reflect in nERR bit)
6. After encoder initialization duration of 500 ms upon power-up, perform an alarm clear command before starting to interface with the encoder.

REGISTER COMMUNICATION AND ASSIGNMENT

Refer to the BiSS-C Interface Protocol Description document for detailed information.
<http://biss-interface.com/download/biss-c-protocol-description-english/>

MEMORY MAP (NON-VOLATILE MEMORY)

There are a total of 10 register banks user areas (register bank 0 to register bank 9) that are accessible by users. The memory data is kept in nonvolatile memory.

BiSS-C		Remarks
Bank	Address	
0	00 ...3Fh	User area
1	00 ...3Fh	
2	00 ...3Fh	
3	00 ...3Fh	
4	00 ...3Fh	
5	00 ...3Fh	
6	00 ...3Fh	
7	00 ...3Fh	
8	00 ...3Fh	
9	00 ...3Fh	
–	40h	Bank selection
–	48 ... 77h	Slave Register (Refer to the Slave Register Description – user area)

Note: EDS bank is not available.

SLAVE REGISTER DESCRIPTION

Address 72 (0x48) - Error status [7...0]

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
NA			MLSErr Error	Multi-turn Counting Error	Single-Turn Counting Error	MemoryErr Error	XCErr Error

Address 73 (0x49) - Warning status [7...0]

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
NA						LisErr Warning	LEDErr Warning

Address 74 (0x4A) - Encoder Clear Command

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
NA				Warning clear command*	Error clear command*	Single-turn clear command*	Multi-turn clear command*

* Encoder Clear Command operation

- a. Write 1 to execute one time clear command
- b. Only one command should be accessed for each time

ALARM DEFINITION

N	Alarms	Alarms definition
1	XCErr Error	To indicate multi-turn block hardware miscount 1 = Hardware miscount occur 0 = No hardware miscount
2	MemoryErr Error	To indicate eeprom content loading status upon encoder power up 1 = Fail to load EEPROM memory data 0 = Success to load EEPROM memory data
3	Single-turn Counting Error	To check integrity of single-turn position 1 = Error in single-turn position 0 = No error in single-turn position
4	Multi-turn Counting Error	To check integrity of multi-turn position 1 = Error in multi-turn position 0 = No error in multi-turn position
5	MLSErr Error	To detect error in MLS (Mcode) generation 1 = MLS code error 0 = MLS code good
6	LedErr Warning	To indicate if LED current is out of operating range 1 = LED out of operating range 0 = LED within operating range
7	LisErr Warning	To check integrity of ADC Sin & Cos signals by means of Lissajous specifications 1 = Lissajous out of specification 0 = Lissajous within specification

NOTE: After encoder initialization duration of 500 ms upon power-up, perform an alarm clear command before starting to interface with the encoder.

GENERAL INSTALLATION NOTES



The transducer must be used in accordance with its specifications. It is a precision measuring instrument and not a safety device.



Personnel responsible for mounting and commissioning the device must be qualified and carefully follow installation instructions. It is strongly recommended to avoid any mechanical or electrical modifications for safety reasons. Any modifications will void the warranty.



To ensure proper functioning, avoid subjecting the device to stress or impact.



Ensure that the mechanical coupling of the transducer is designed as specified in the technical datasheet and that the product is installed according to the instructions provided.



Additionally, check that the operating environment is free from corrosive agents (such as acids) or substances that are incompatible with the device and its IP rating.



Ensure the device is properly grounded. If necessary, provide an additional external connection.



Products with variant codes (a number or combination of numbers after “.”) may have different mechanical, electrical, or connection requirements than standard products. Please refer to the additional documentation.



Installation and wiring should only be performed by trained personnel in a POWER-OFF condition.



To prevent short-circuits, insulate any unused wires at varying lengths. Do not connect unused pins on the connector.



Before switching on, verify the voltage range applicable for the device.



Place power and signal cables in a way that avoids capacitive or inductive interferences that may cause device malfunction. Also, keep the transducer cable far from power lines or any other cable with high noise levels.



The user who integrates the transducer into their appliance must comply with CE/UKCA regulations and is responsible for marking the end machine/device.



Failure to observe these usage and installation precautions may void the warranty.



Eltra disclaims any liability for damages or injuries resulting from non-compliance with these directives.



The products should be stored in their original packaging in a dust-free, dry and temperature-regulated location that is free from chemical influences or mechanical shock/vibrations.



Via Guido Salvagnini, 17 - 36040 - Sarego - Vicenza - ITALY
T: +39 0444 436489 | F: +39 0444 835335 | eltra.it@broadcom.com

www.eltra.it